

# STUDY OF DEWETTING IN THIN POLYMER FILMS


VINAY NUKA, MANINDERJEET SINGH, ALAMGIR KARIM

## BACKGROUND / INTRODUCTION

- ❑ Dewetting is a phenomenon that occurs at the solid-liquid interface where the liquid retracts from the non-wettable solid it was forced to cover
- ❑ This process can be observed in macroscale but is taken to microscale (polymer films) to observe various interesting mechanisms at different processing temperatures and timescales
- ❑ The polymer film is used to study the various stages of Dewetting at and above the Glass Transition temperature with the help of an Optical Microscope
- ❑ By controlling parameters such as time, temperature, etc. controlled dewetted structures can be obtained on a variety of substrates which are useful for templating nanoparticles as well as in lithography applications

## OVERVIEW OF THE EXPERIMENT

- PolyStyrene (2k) – 20mg is taken into a 2ml vial and Toluene-1ml is then added in order to prepare a 2% (wt/V) solution
- The solution is then filtered using a 0.2  $\mu\text{m}$  filter
- The silicon substrate is pre cleaned with Toluene and placed in UV-Ozone system to remove any impurities and etch any unwanted oxides
- A procedure named Flow coating is used to make the polymer film





## RESULTS FROM THE TESTS

- Polymer film annealed at 70°C (glass transition temperature) for 5 mins under 30 psig vacuum



Note: All the images are scaled to 50 $\mu\text{m}$





- 80°C for 5 mins under 30 psig vacuum





- 80°C for 10 mins under 30 psig vacuum



- 90°C for 5 mins under 30 psig vacuum



- 90°C for 10 mins under 30 psig vacuum




- 115°C for 10 mins under 30 psig vacuum




## ANALYSIS OF THE SCANS

The representative images of various stages have been displayed on a Temperature-time graph to understand dewetting behavior with change in the parameters




## FUTURE WORK

- ❖ Software will have the necessary code to evaluate dewetting images for automatic recognition to describe the dewetting stage i.e. temperature and time
- ❖ Upon scanning the film at different locations, MATLAB will receive the data



- ❖ For example, on selecting “Scan 1”, MATLAB will give the following command.



## ACKNOWLEDGEMENTS

I would like to extend my gratitude to Dr.Alamgir Karim for funding and guiding me throughout the Project. I am also grateful to the Graduate students in the lab for their willingness to advice me to overcome several challenges